

# SITE READINESS

January // 2025

---

## BE SITE READY

- Ensure the house number is visible from the street if in a urban area.
- The site is backfilled and is within 150 mm (6 inches of finished grade).
- The site allows for three meters of access between buildings and the property line for both people and equipment.
- The trench route should be clear of debris or obstructions like trees, dirt and lumber.
  - We will determine an alternate route if anything is restricting access for people or equipment. The new routing and costs, as applicable, will need to be pre-approved before construction starts.
  - Note: Any refinishing of the Site following completion of the work will be at the Customer's cost. This will be outlined on your quote letter.
- If applicable, the natural gas trench (SaskEnergy) must be at least one meter from the SaskPower trench.
  - If you need both power and gas service installation, we recommend applying for natural gas service at the same time as power, so both crews can coordinate construction.
  - If both services are being installed in a joint trench, it must be large enough to ensure one meter distance between the natural gas and power lines.
- Your electrician has attached an energization sticker on the meter socket. This indicates the service is ready for connection. This sticker also ensures:
  - You have an electrical permit.
  - The main panel is connected and in the “off” position.
  - The service is grounded and ready to be connected to SaskPower.